

Motorola XTL5000 Series Consolette Radio



Power Button - NOT PROGRAMMED
Unit powers ON when plugged in
Channel Select (MODE)
Volume Control

Dim Button - Cycles DIM feature
HOME Button - Not Programmed



ZONE UP / ZONE DOWN — Zone name changes and you are locked into each zone as it changes. Channel is changed with the channel (Mode) rocker switch highlighted in blue above.



Motorola XTL5000 Series Consolette



SCAN ON & OFF — (On = ▲)

Nuisance Delete when scanning

Restore nuisance deleted channels to scan list

Zone → Name	SE1
Channel 1	SE1-PSAP
Channel 2	SE1-MED
Channel 3	SE1-EOC
Channel 4	SE1-LE
Channel 5	SE1-EMGT
Channel 6	SE1-FIRE
Channel 7	SE1-EMS
Channel 8	SE1-PWKS
Channel 9	
Channel 10	
Channel 11	
Channel 12	
Channel 13	
Channel 14	
Channel 15	
Channel 16	

Used to talk to 9-1-1 Dispatch Centers.

Used to talk to Hospitals and EMS agencies.

Used to talk to Emergency Operations Centers and Emergency Managers.

Regional Law Enforcement Group - Only associates within the region.

Regional Emergency Management Group - Only associates within the region.

Regional Fire Group - Only associates within the region.

Regional Emergency Medical Group - Only associates within the region.

Regional Public Works Group - Only associates within the region.

Channels 9 through 16 will either be KHP Event Channels or will be unprogrammed. Event Channels are available for legitimate use without further authorization. They are statewide talkgroups.

